

Stovetop and Grill



1. When starting the pilot light of gas stove or grill use the following procedure:
 - a. Turn off all gas controls.
 - b. Wait five minutes.
 - c. Open the pilot burner or lighting rod adjusting the valve $\frac{1}{4}$ turn.
 - d. Light the pilot or lighting rod with a match.
 - e. Adjust flame so there is a slight yellow tip.

Note: refer to the stove or grill operator's manual for specific instructions before lighting

2. When using the stovetop or oven:
 - a. Do not allow potholders, loose clothing, or long hair to hang down near the flame. b. Do not turn on the flame on stovetop when there is not a pan on it.
 - b. Turn handles of pots and pans in toward the center of the stove.
 - c. Do not store pans in the oven of the stove, as the pilot light alone could causes the pan to be hot.