

Chop Saws



1. Read and understand the Operator's Manual.
2. Employees will be properly and thoroughly trained before attempting to do any work with or on any chop saw.
3. It is the duty of each operator to immediately eliminate or report any changes occurring on the machine or in the material being processed which changes may affect the machine's safe operation.
4. HAVE the power disconnected when making any adjustment or changing blades.
5. DO NOT wear loose clothing.
6. ALWAYS WEAR safety glasses or a face shield.
7. ALWAYS HOLD the work firmly against the fence or firmly secured in supports.
8. GUARDS must be in place and used at all times.
 - a. DO NOT switch on the machine until all safety devices and guards are in proper position and adjustment and are fully operational.
9. REMOVE CHIPS and pieces of scrap from table before using machine.
10. BE SURE blade is free cutting, secured, free from chips, cracks, and vibration. NEVER use a defective blade.
11. Allow the motor to come up to full speed before starting cut.
12. Use extreme caution when using the saw near flammable materials.
 - a. The blade may "throw" sparks when it contacts the item you are cutting and may ignite nearby materials.